



































| Original    | Replacement  | Original   | Replacement   |
|-------------|--|------------|---|
| On/Off      |  Power          | OK Enter   |  Ok    |
| Mute        |  Mute           | Menu Right |  Right |
| Update      |  Smart          | Menu Off   |  Exit  |
| Reveal      |  Media          | Menu Down  |  Down  |
| Txt Stop    |  Stop           | Back       |  Back  |
| Info        |  Info           | Volume+    |  Vol + |
| Subt.List   |  Subt           | Chan.Up    |  Ch +  |
| Sleep Timer |  Sleep          | Volume-    |  Vol - |
| Return TV   |  TV/R           | Menu audio |  Dual  |
| Menu video  |  D. Menu        | Chan.Down  |  Ch -  |
| Text        |  Text         | 1          |  1   |
| Txt Expand  |  Eject        | 2          |  2   |
| TV/AV       |  AV           | 3          |  3   |
| Menu        |  Menu         | 4          |  4   |
| Menu Up     |  Up           | 5          |  5   |
| Display     |  Shift + Info | 6          |  6   |
| Menu Left   |  Left         | 7          |  7   |



| Original      | Replacement  | Original       | Replacement  |
|---------------|--|----------------|--|
| 8             |  8  | Tone-          |  I<<  |
| 9             |  9  | Tune-          |  +  Shift + Left       |
| Guide -/-- 1. |  Guide  | Aft/Caf        |  +  Shift + Ok         |
| 0/10          |  0  | Tune+          |  +  Shift + Right      |
| 2.Fav P/C 2.  |  Pre Ch   | Bright- Sys    |  +  Shift + Exit       |
| Red           |  Red  | Contrast+      |  +  Shift + Ch +       |
| Green         |  Green  | Contrast-      |  +  Shift + Ch -       |
| Yellow        |  Yellow   | Color- S.Std   |  +  Shift + Dual       |
| Mix Scan      |  Options  | 3.*            |  +  Shift + Guide      |
| On/Tim        |  List   | 4.# 16:9       |  Format   |
| Off/Tim       |  +  Shift + List     | Surround       |  +  Shift + Red      |
| Blue          |  Blue   | Nicam/Mono     |  +  Shift + Green  |
| Tone+         |  >>I  | Level L        |  +  Shift + Yellow |
| Disp          |  3D   | Level R/Woofer |  +  Shift + Blue   |
| Audio-        |  <<   |                |  |
| Color+ P.Std  |  +  Shift + Format |                |  |
| Audio+        |  >>   |                |  |

