







































































Original	Replacement	Original	Replacement
 Standby	 Power	 Aspect	 Format
 Mute	 Mute	 Info. / Display	 Info
 1	 1	 CH+	 Ch +
 2	 2	 CH-	 Ch -
 3	 3	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 Right	 Right
 7	 7	 Down	 Down
 8	 8	 Menu	 Menu
 9	 9	 Source	 AV
 0	 0	 Exit	 Exit
 -/--	 Shift + Guide	 Freeze	 Pause
 Recall	 Back	 P.Mode	 Shift + Format
 Vol+	 Vol +	 S.Mode	 Shift + Dual
 Vol-	 Vol -	 FAV	 Pre Ch
 Sleep	 Sleep	 EPG	 Guide



