



Original	Replacement	Original	Replacement
 Power	 Power	 Info	 Info
 Mute	 Mute	 Menu	 Menu
 1	 1	 Exit	 Exit
 2	 2	 Text	 Text
 3	 3	 EPG	 Guide
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 OK	 Ok
 9	 9	 Stop	 Stop
 0	 0	 Play	 Play
 Timeshift	 Media	 Pause	 Pause
 Recall	 Back	 <<	 <<
 Mark	 Smart	 >>	 >>
 Tv/Radio	 TV/R	 Rec	 Rec
 Source	 AV	 I<<	 I<<



