







































































Original	Replacement	Original	Replacement
 Power	 Power	 YouTube	 Shift + Media
 Input	 AV	 Menu	 Menu
 1	 1	 Up	 Up
 2	 2	 Netflix	 Media
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 Right	 Right
 6	 6	 Down	 Down
 7	 7	 Exit	 Exit
 8	 8	 Vol+	 Vol +
 9	 9	 Back	 Back
 0	 0	 Vol-	 Vol -
 Info	 Info	 Guide	 Guide
 Recall	 Pre Ch	 Mute	 Mute
 Prime Video	 Shift + Smart	 Ch+	 Ch +
 Home	 Smart	 Ch-	 Ch -
 Q.Menu	 D. Menu	 Red	 Red



