



Original	Replacement
	Power
	Back / Return
	Mute / Dimmer
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Fav / Marker / PC
	0
	Guide / EPG / - / -
	Info / Angle
	Audio / Lang I/II

Original	Replacement
	Up
	CH+ / Page+
	Left
	OK
	Menu / Home
	Right
	Down
	CH- / Page-
	Vol -
	Vol +
	Red / Netflix / Search
	Sound / Title
	Green / APP / Repeat
	Picture / Format
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Display / Media



