
































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 [≡]	 Text
 1	 1	 Back	 Back
 2	 2	 CH+	 Ch +
 3	 3	 CH-	 Ch -
 4	 4	 Vol+	 Vol +
 5	 5	 Vol-	 Vol -
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 OK	 Ok
 Red	 A	 ↑/[+]	 Pre Ch
 Green	 B	 F.T/L	 Options
 Yellow	 C	 [?]	 3D
 Blue	 D	 [♦]	 Format
 TV / DTV	 TV/R	 ↓/[]	 Guide





Original		Replacement		Original	Replacement
	Power		Power		
	Menu		Menu		
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
	OK		Ok		
	Top Menu	 + 	Shift + Menu		
	Back		Back		
	↑/[+]		Pre Ch		
	↓/[]		Guide		
	<<		<<		
	Play		Play		
	>>		>>		
	Stop		Stop		
	Pause		Pause		



