




































































































Original		Replacement		Original		Replacement	
	POWER		Power		6		6
	TELETEXT		Text		7		7
	Index		Play		8		8
	Clock / Subpage		Pause		9		9
	Hold		Stop		0		0
	Reveal		Rec		MUTE		Mute
	Cancel		<<		RTN.		Back
	Size		>>		CH+		Ch +
	RED		Red		CH-		Ch -
	GREEN		Green		VOL+		Vol +
	YELLOW		Yellow		VOL-		Vol -
	BLUE		Blue		ARC		Smart
	1		1		APC		Media
	2		2		UP		Up
	3		3		LEFT		Left
	4		4		OK		Ok
	5		5		RIGHT		Right





Original		Replacement		Original		Replacement	
	DOWN		Down		PIP POSITION	 + 	Shift + Smart
	MENU		Menu				
	EXIT		Exit				
	TV	 + 	Shift + Red				
	PC / HD	 + 	Shift + Green				
	VIDEO	 + 	Shift + Yellow				
	SCART	 + 	Shift + Blue				
	SOUND		Dual				
	SUB-TITLE		Subt				
	GUIDE		Guide				
	SLEEP		Sleep				
	PIP ON/OFF	 + 	Shift + Ok				
	PIP SWAP	 + 	Shift + Left				
	PIP SWAP	 + 	Shift + Right				
	PIP SOURCE UP	 + 	Shift + Up				
	PIP SOURCE	 + 	Shift + Down				
	PIP SIZE	 + 	Shift + Media				

