























































Original		Replacement		Original		Replacement	
	Power		Power		Vol+		Vol +
	Energy Saving		Shift + 3D		Vol-		Vol -
	AV Mode		Shift + AV		Mark / FAV / Char/Num		Pre Ch
	Input		AV		3D		3D
	TV/RAD		TV/R		Mute		Mute
	1		1		P+/Page Up		Ch +
	2		2		P-/Page Down		Ch -
	3		3		Smart TV		Shift + Smart
	4		4		Smart TV Home		Smart
	5		5		Q.Menu/3D		Menu
	6		6		Up		Up
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Right		Right
	0		0		Down		Down
	List		List		Back		Back
	Q.View		D. Menu		Guide		Guide





Original		Replacement		Original	Replacement
	Exit		Exit		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		
	Text		Text		
	T.Opt		Options		
	Subtitle		Subt		
	Stop		Stop		
	Play		Play		
	Pause		Pause		
	<<		<<		
	>>		>>		
	[]/Ratio		Format		
	Info		Info		
	AD		Shift + Subt		
	APP/*		Media		

