













































































Original	Replacement
 Power	 Power
 Input	 AV
 Text	 Text
 T.Opt	 Options
 AD	 Subt
 *	 Menu
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0 / Quick Access	 0
 List	 List

Original	Replacement
 ...	 3D
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Search	 Shift + TV/R
 TV	 TV/R
 CH+	 Ch +
 CH-	 Ch -
 Home	 Smart
 Netflix	 Shift + Red
 Prime Video	 Shift + Green
 Disney+	 Shift + Blue
 Rakuten TV	 Shift + Yellow
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right





Original	Replacement	Original	Replacement
 Down	 Down		
 Back	 Back		
 Exit	 Exit		
 Guide	 Guide		
 Rec	 Rec		
 Stop	 Format		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

