



Original	Replacement
 Power	 Power
 Search	 Source
 RGB	 Invert 3D / Invert
 Video	 Video Comp / Video
 Aspect	 Aspect Eco / Aspect
 Auto	 Auto
 Blank	 Mute Blank / Blank / Mute
 Magnify On	 Focus Volt / Volt / Focus
 Magnify Off	 Info Help / Help / Info
 Home	 Mode
 End	 Shift + Menu / Shift + Menu
 Page Up	 Shift + Page Up / Shift + Vol + / Page +
 Page Down	 Shift + Page Down / Shift + Vol - / Page -
 Volume	 Page Up Vol / Vol + / Page +
 Mute	 Shift + Mute Blank / Shift + Blank / Mute
 Freeze	 Timer Freeze / Freeze / Timer
 My Button 1	 Play + / + / Play

Original	Replacement
 My Button 2	 Stop - / Stop
 Keystone	 Page Vol / Vol - / Page -
 Menu	 Menu
 Esc	 Shift + Power / Shift + Power
 Position	 Shift + Auto / Shift + Auto
 Reset	 Shift + Mode / Shift + Mode
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Enter

