



	Original	Replacement		Original	Replacement
	Power		Power		8
	Mute		Mute		9
	ATV/DTV		Smart		0
	NR.		Play		-/--
	Still		Pause		Recall
	Aspect		Format		Volume+
	Sleep		Sleep		Volume-
	Nicam/A2		Dual		Channel+
	Surround		List		Channel-
	Bass		Options		Source
	1		1		Picture
	2		2		Sound
	3		3		Info
	4		4		ATV Menu
	5		5		DVB Menu
	6		6		Exit
	7		7		TTX
					8
					9
					0
					Shift + Guide
					Back
					Vol +
					Vol -
					Ch +
					Ch -
					AV
					Shift + Format
					Shift + Dual
					Info
					Menu
					D. Menu
					Exit
					Text





Original	Replacement	Original	Replacement
 Up	 Up	 PIP On/Off	 Shift + 1
 Left	 Left	 PIP Position	 Shift + 2
 OK	 Ok	 PIP Size	 Shift + 3
 Right	 Right	 PIP Window	 Shift + 4
 Down	 Down	 PIP Swap	 Shift + 5
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 EPG / [=i]	 Guide		
 FAV / [=◆]	 Pre Ch		
 Sub-T / [=□]	 Subt		
 Audio / [=X]	 Media		
 TV/RD / [=●]	 TV/R		
 Timer / [=?]	 Shift + AV		
 [=◇]	 3D		
 [=...]	 Shift + Subt		

