











































Original	Replacement
 DVD Power	 Power
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 Prog/Direct	 Sleep
 Call	 Pre Ch
 Clear	 Exit
 Random	 Media

Original	Replacement
 Subtitle	 Subt
 Audio	 Dual
 Repeat	 Text
 A-B Repeat	 AV
 Menu	 Menu
 Top Menu/PBC	 Shift + Menu
 Angle	 Red
 Return	 Back
 Up	 Up
 Enter	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 Display	 Info
 Stop	 Stop
 Still/Pause	 Pause
 Play	 Play





Original	Replacement	Original	Replacement
 << Slow/Search	 <<		
 >> Slow/Search	 >>		
 I<< Skip	 I<<		
 >>I Skip	 >>I		
 NTSC/PAL	 Format		
 Setup	 Options		
 Zoom	 Shift + Eject		
 Slide Show	 Smart		

