







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Play		Play
	Pause		Pause
	Stop		Stop
	Rec		Rec
	<<		<<
	l<<		l<<
	>>l		>>l
	>>		>>
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Back
	EPG		Guide
	Menu		Menu
	Sources		AV
	Info		Info
	Smart		Smart
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -





Original	Replacement	Original	Replacement
	Shift + Smart		
	Ch +		
	Ch -		
	Media		
	Shift + Media		
	Red		
	Yellow		
	Green		
	Blue		
	Dual		
	Text		
	Subt		

