































































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	[]		Smart
	[≡]		Text
	Input		AV
	Output		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide
	C		Pre Ch
	[*]		TV/R
	[↔*]		Subt
	[↑*]		Sleep
	[↑]		Options
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[≡+]		3D
	[> <]		List
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	[+]		Info
	SAT		Back





Original		Replacement		Original		Replacement	
	Picture		Format				
	[+]		Eject				
	♪		Dual				
	Up/+		Up				
	Down/-		Down				
	←		Left				
	Menu		Menu				
	OK		Ok				
	Power MDP		Shift + Power				
	>> MDT		>>				
	Play MDT		Play				
	<< MDT		<<				
	Stop MDT		Stop				
	Pause MDT		Pause				
	Prog+ MDT		Shift + Ch +				
	Prog- MDT		Shift + Ch -				



