










































































































| Original | Replacement |
|--|--|
|  Power |  Power |
|  Tuner |  Shift + 6 |
|  Source |  AV / Input / RDS |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  . |  Setup / OPT / |
|  Mute |  Mute / Dimmer |
|  You Tube |  Shift + Yellow / YouTube / |
|  Internet |  Display / Media |

| Original | Replacement |
|--|---|
|  Home |  Shift + Menu / |
|  Netflix |  Shift + Red / Netflix / |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  * |  Menu / Home |
|  Up |  Up |
|  Down |  Down |
|  Right/Zoom+ |  Right |
|  Left/Zoom- |  Left |
|  OK |  OK |
|  Back |  Back / Return |
|  Exit |  Exit / Cancel / Clear |
|  Info |  Info / Angle |
|  USB |  Shift + 8 |
|  = |  Text / Goto |





| Original | Replacement |
|---|---|
|  Sleep |  Sleep / Timer |
|  Guide |  Guide / EPG / -/-- |
|  FAV |  Fav / Marker / PC |
|  CH.List |  Smart / List |
|  Picture |  Picture / Format |
|  Sound |  Sound / Title |
|  CC |  Subtitle / EQ |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |
|  Blue |  Blue / Prime Video / Random |
|  I< |  I<< / Preset- |
|  Stop |  Stop / Hold |
|  Play |  Play / Slow |
|  Pause |  Pause / Step / Freeze |
|  >I |  >>I / Preset+ |
| << button" data-bbox="228 941 261 974"/> |  << / Tune- |

| Original | Replacement |
|---|--|
|  >> |  >> / Tune+ |
|  MTS |  D.Menu / Top |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

