


































Original	Replacement	Original	Replacement
 Power	 Power	 Play	 Play / Slow
 Open/Close	 Eject / Surround	 Pause/Step	 Pause / Step / Freeze
 1	 1	 Stop	 Stop / Hold
 2	 2	 DVD Menu	 D.Menu / Top
 3	 3	 Title	 Sound / Title
 4	 4	 Up	 Up
 5	 5	 Enter	 OK
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 Return	 Back / Return
 0	 0	 Display	 Display / Media
 Clear	 Exit / Cancel / Clear	 Audio	 Audio / Lang I/II
 <<	 << / Tune-	 Subtitle	 Subtitle / EQ
 >>	 >> / Tune+	 Angle	 Info / Angle
  <<	  << / Preset-	 Setup	 Setup / OPT /
 >>	 >>  / Preset+	 Marker	 Fav / Marker / PC

Original	Replacement	Original	Replacement
 Power	 Power	 Play / Slow	 Play / Slow
 TV	 DVD	 SAT	 AUX
 SLOW	 STEP-FREEZE	 HOLD	 REC MODE
 TUNE-	 TUNE+	 PRESET-	 PRESET+
 TITLE	 LANG I/II	 EQ	 SURROUND
 SOUND	 AUDIO	 SUBTITLE	 PROGRAM
 FORMAT	 SIZE	 TIMER	 TV RADIO
 PICTURE	 ZOOM	 SLEEP	 RDS
 TOP MENU	 OPT-TOOLS	 GOTO	 AV INPUT
 D.MENU	 SETUP	 TEXT	 HOME
 HOME	 ANGLE	 INFO	 MENU
 MENU	 Up	 Up	 OK
 OK	 Down	 Down	 EXIT
 EXIT	 Right	 Right	 CANCEL
 CANCEL	 Left	 Left	 LIST
 LIST	 SMART	 CH PAGE	 + VOL
 + VOL	 MEDIA	 DISPLAY	 - VOL
 - VOL	 TV	 DVD	 CD - STB
 CD - STB	 1	 2	 3
 3	 VIDEO	 TAPE	 TUNER
 TUNER	 4	 5	 6
 6	 AUX - HDD	 USB	 BLUETOOTH
 BLUETOOTH	 7	 8	 9
 9	 GUIDE EPG	 HDMI - BAT	 PC
 PC	 0	 FAV MARKER	 NETFLIX
 FAV MARKER	 SEARCH	 REPEAT	 APP
 REPEAT	 REPEAT A-B	 RANDOM	 YouTube
 RANDOM	 Mandis SHOP	 www.mandis.tv	 Prime Video





	Original	Replacement	Original	Replacement
	Search	Red / Netflix / Search		
	Program	Shift + TV/Radio / Program		
	Zoom	Zoom / Size		
	Repeat	Green / APP / Repeat		
	A-B	Yellow / YouTube / Repeat		
	Resolution	TV/Radio /		
	*	Blue / Prime Video / Random		
	Power Tv	Shift + Power		
	AV Tv	AV / Input / RDS		
	PR/CH+ Tv	CH+ / Page+		
	PR/CH- Tv	CH- / Page-		
	Vol+ Tv	Vol+		
	Vol- Tv	Vol-		

