










































































































Original	Replacement
 Open/Close	 Eject / Surround
 Standby Tv	 Shift + Power
 Standby	 Power
 1 Tv	 Shift + 1
 2 Tv	 Shift + 2
 2	 2
 3 Tv	 Shift + 3
 1	 1
 4 Tv	 Shift + 4
 3	 3
 4	 4
 5 Tv	 Shift + 5
 5	 5
 6 Tv	 Shift + 6
 7 Tv	 Shift + 7
 6	 6
 8 Tv	 Shift + 8

Original	Replacement
 7	 7
 9 Tv	 Shift + 9
 8	 8
 9	 9
 0 Tv	 Shift + 0
 0	 0
 -/-- Tv	 Guide / EPG / -/--
 10	 Shift + Guide / EPG / -/--
 +10	 Fav / Marker / PC
 Return	 Back / Return
 Page	 Setup / OPT /
 Title/Group	 Info / Angle
 Tv/Video	 Shift + TV/Radio / Program
 Cancel	 Exit / Cancel / Clear
 Top Menu	 D.Menu / Top
 Choice	 TV/Radio /
 Menu	 Menu / Home





Original	Replacement
 CH+ Tv	 Shift + CH+ /
 Up	 Up
 CH- Tv	 Shift + CH- /
 Vol- Tv	 Shift + Vol-
 Down	 Down
 Vol+ Tv	 Shift + Vol+
 Right	 Right
 Enter	 OK
 Left	 Left
 I<</Previous	 I<< / Preset-
 On Screen	 Display / Media
 >>I/Next	 >>I / Preset+
 Stop/Clear	 Stop / Hold
 Play/Select	 Play / Slow
 Pause/Strobe	 Pause / Step / Freeze
 <</Slow-	 << / Tune-
 >>/Slow+	 >> / Tune+

Original	Replacement
 Repeat	 Green / APP / Repeat
 Subtitle	 Subtitle / EQ
 Audio/fs/Rate	 Audio / Lang I/II
 VFP/Progressive Scan	 Picture / Format
 Digest	 AV / Input / RDS
 Angle	 Shift + Info / Angle
 Zoom-	 CH- / Page-
 Zoom+	 CH+ / Page+
 3D Phonic	 Zoom / Size
 PAL/NTSC	 Sleep / Timer
 Amp Vol-	 Vol-
 Amp Vol+	 Vol+
 Muting Tv	 Mute / Dimmer

