





































Original	Replacement
 On	 Power
 Off	 Shift + Power
 N	 Smart / List
 R	 Display / Media
 [+]	 Info / Angle
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 ■	 OK
 Pos/Size	 Shift + Zoom /
 []/Picture	 Picture / Format
 J/Sound	 Sound / Title
 Set Up	 Setup / OPT /
 Input 1	 Red / Netflix / Search
 Input 2	 Green / APP / Repeat
 Input 3	 Yellow / YouTube / Repeat

Original	Replacement
 PC	 Fav / Marker / PC
 Input	 AV / Input / RDS
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 Vol+	 Vol+
 Vol-	 Vol-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0



















Original		Replacement	
	C/ID Set	+	Shift + Setup / OPT / Tools
	-/--/ID All		Guide / EPG / -/--
	[+]/Aspect	+	Shift + Picture / Format
	Surround		Eject / Surround
	Off Timer		Exit / Cancel / Clear
	Multi PIP		D.Menu / Top
	Swap		Back / Return
	Select	+	Shift + OK
	Zoom/Movie		Zoom / Size

Original		Replacement	












Original	Replacement	Original	Replacement
On	 Power	CH-	 CH- / Page-
N	 Smart / List	Vol+	 Vol+
R	 Display / Media	Vol-	 Vol-
[+]	 Info / Angle	1	 1
Off	 +  Shift + Power	2	 2
■	 OK	3	 3
Up	 Up	4	 4
Down	 Down	5	 5
Right	 Right	6	 6
Left	 Left	7	 7
Input 1	 Red / Netflix / Search	8	 8
Input 2	 Green / APP / Repeat	9	 9
Input 3	 Yellow / YouTube / Repeat	0	 0
PC	 Fav / Marker / PC	[]/Picture	 Picture / Format
Input	 AV / Input / RDS	J/Sound	 Sound / Title
Mute	 Mute / Dimmer	Set Up	 Setup / OPT /
CH+	 CH+ / Page+	Pos Size	 Text / Goto





Original	Replacement	Original	Replacement
[+]/Aspect	 +  Shift + Picture / Format		
Surround	 Eject / Surround		
Off Timer	 Exit / Cancel / Clear		
Multi PIP	 Zoom / Size		
Swap	 Back / Return		
Zoom/Movie	 TV/Radio /		

