




































































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 Info	 Info / Angle
 4	 4
 5	 5
 6	 6
 POS	 Display / Media
 7	 7
 8	 8
 9	 9
 Audio	 Audio / Lang I/II
 0 / Multi Pict	 0
 Red / Text	 Red / Netflix / Search
 Red / Text	 Text / Goto
 Green / TV/AV	 Green / APP / Repeat

Original	Replacement
 Green / TV/AV	 AV / Input / RDS
 Blue / Pause	 Blue / Prime Video / Random
 Blue / Pause	 Pause / Step / Freeze
 Yellow / Subtitle	 Yellow / YouTube / Repeat
 Yellow / Subtitle	 Subtitle / EQ
 White / Zoom	 Zoom / Size
 Up / PR+	 Up
 Up / PR+	 CH+ / Page+
 Mute	 Mute / Dimmer
 Left / Vol- / >>I	 Left
 Left / Vol- / >>I	 >>I / Preset+
 Left / Vol- / >>I	 Vol-
 OK / List	 OK
 OK / List	 Smart / List
 Right / Vol+ / I<<	 Right
 Right / Vol+ / I<<	 Vol+
 Right / Vol+ / I<<	 I<< / Preset-



