















































Original	Replacement
	 Power
	 CD - STB 3
	 Tuner 6
	 Tape 5
	 AUX - HDD 7
	 SHIFT +  TIMER SLEEP Shift + Sleep / Timer
	 TIMER SLEEP Sleep / Timer
	 Vol-
	 Vol+
	 << / Tune-
	 >> / Tune+
	 LIST SMART Smart / List
	 MEDIA DISPLAY Display / Media
	 DIMMER MUTE Mute / Dimmer
	 CH PAGE - CH- / Page-
	 CH PAGE + CH+ / Page+

Original	Replacement










Original	Replacement
 Power	 Power
 CD	 3
 Tuner	 6
 Tape	 5
 AUX	 7
 Mode	 Picture / Format
 Timer	 Shift + Sleep / Timer
 Sleep	 Sleep / Timer
 Vol-	 Vol-
 Vol+	 Vol+
 I<	 I<< / Preset-
 >I	 >>I / Preset+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 <<	 << / Tune-
 >>	 >> / Tune+

Original	Replacement
 DSC	 Smart / List
 IS/DBB	 Display / Media
 Mute	 Mute / Dimmer
 Album/Preset	 CH- / Page-
 Album/Preset	 CH+ / Page+





Original	Replacement
	 Power
	 3
	 6
	 5
	 7
	 +  Shift + Sleep / Timer
	 Sleep / Timer
	 Vol-
	 Vol+
	 I<< / Preset-
	 >>I / Preset+
	 Stop / Hold
	 Play / Slow
	 Pause / Step / Freeze
	 << / Tune-
	 >> / Tune+
	 Smart / List

Original	Replacement
	 Display / Media
	 Mute / Dimmer





	Original	Replacement	
	Power	 Power	
	CD	 3	
	Tuner	 6	
	Tape	 5	
	AUX	 7	
	Timer	 +  Shift + Sleep / Timer	
	Sleep	 Sleep / Timer	
	Vol-	 Vol-	
	Vol+	 Vol+	
	DSC	 Smart / List	
	IS/DBB	 Display / Media	
	Mute	 Mute / Dimmer	

Original	Replacement

