



































































































Original	Replacement
 Power	 Power
 Source	 AV / Input / RDS
 Text	 Text / Goto
 T.Opt	 Setup / OPT /
 AD	 Audio / Lang I/II
 *	 Menu / Home
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List
 0	 0

Original	Replacement
 ...	 Fav / Marker / PC
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Search	 Display / Media
 CH-	 CH- / Page-
 TV	 TV/Radio /
 Netflix	 Shift + Red / Netflix /
 Home	 Shift + Menu /
 prime video	 Shift + Blue / Prime
 Disney+	 Shift + Yellow / YouTube /
 Up	 Up
 Movies	 Shift + Green / APP /
 Left	 Left
 OK	 OK
 Right	 Right





Original	Replacement	Original	Replacement
 Back	 Back / Return		
 Down	 Down		
 [->]	 Exit / Cancel / Clear		
 Guide	 Guide / EPG / -/--		
 Rec	 Rec / Rec Mode		
 Stop	 Stop / Hold		
 <<	 << / Tune-		
 Play	 Play / Slow		
 Pause	 Pause / Step / Freeze		
 >>	 >> / Tune+		
 Red	 Red / Netflix / Search		
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		

