




















































Original	Replacement
	 Mute / Dimmer
	 Info / Angle
	 Power
	 Eject / Surround
	 Setup / OPT /
	 Audio / Lang I/II
	 Text / Goto
	 AV / Input / RDS
	 Sleep / Timer
	 Up
	 Menu / Home
	 Back / Return
	 Down
	 OK
	 Smart / List
	 1
	 2

Original	Replacement
	 3
	 Picture / Format
	 4
	 5
	 6
	 Shift + Sleep / Timer
	 7
	 8
	 9
	 Zoom / Size
	 Guide / EPG / -/--
	 0
	 Exit / Cancel / Clear
	 Vol+
	 CH+ / Page+
	 Red / Netflix / Search
	 Green / APP / Repeat





Original	Replacement
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Vol-
	CH- / Page-
	Rec / Rec Mode
	Shift + Setup / OPT / Tools
	Sound / Title
	Subtitle / EQ
	Shift + Text /
	Pause / Step / Freeze
	I<< / Preset-
	>>I / Preset+
	<< / Tune-
	Play / Slow
	>> / Tune+
	Stop / Hold

Original	Replacement

