



















































Original	Replacement
 Power	 Power
 DVD	 Shift + 2
 Open / Close	 Eject / Surround
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Return	 Back / Return
 0	 0
 Display	 Display / Media
 Disc Menu	 D.Menu / Top
 Up	 Up

Original	Replacement
 System Menu	 Menu / Home
 Left	 Left
 OK	 OK
 Right	 Right
 I<<	 I<< / Preset-
 Down	 Down
 >>I	 >>I / Preset+
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause / Step	 Pause / Step / Freeze
 Marker	 Fav / Marker / PC
 Search	 Red / Netflix / Search
 Subtitle	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 Angle	 Info / Angle
 Zoom	 Zoom / Size
 Repeat	 Green / APP / Repeat







































Original	Replacement																																																																										
<table border="1"> <tr> <td>REPEAT A-B</td> <td>Repeat A-B</td> </tr> <tr> <td>PROGRAM</td> <td>Program</td> </tr> <tr> <td>CLEAR</td> <td>Clear</td> </tr> <tr> <td>TITLE</td> <td>Title</td> </tr> <tr> <td>SHUFFLE</td> <td>Shuffle</td> </tr> </table>	REPEAT A-B	Repeat A-B	PROGRAM	Program	CLEAR	Clear	TITLE	Title	SHUFFLE	Shuffle	<table border="1"> <tr> <td></td> <td>Yellow / YouTube / Repeat</td> </tr> <tr> <td></td> <td>TV/Radio /</td> </tr> <tr> <td></td> <td>Exit / Cancel / Clear</td> </tr> <tr> <td></td> <td>Sound / Title</td> </tr> <tr> <td></td> <td>Blue / Prime Video / Random</td> </tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> <tr><td> </td><td> </td></tr> </table>		Yellow / YouTube / Repeat		TV/Radio /		Exit / Cancel / Clear		Sound / Title		Blue / Prime Video / Random																																																						
REPEAT A-B	Repeat A-B																																																																										
PROGRAM	Program																																																																										
CLEAR	Clear																																																																										
TITLE	Title																																																																										
SHUFFLE	Shuffle																																																																										
	Yellow / YouTube / Repeat																																																																										
	TV/Radio /																																																																										
	Exit / Cancel / Clear																																																																										
	Sound / Title																																																																										
	Blue / Prime Video / Random																																																																										

Original	Replacement





Original	Replacement
	 Power
	 TV / Video
	 VCR
	 Eject
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Display / Media
	 Up
	 Menu / Home

Original	Replacement
	 Left
	 OK
	 Right
	 I<< / Preset-
	 Down
	 >>I / Preset+
	 Stop / Hold
	 Play / Slow
	 Pause / Step / Freeze
	 Fav / Marker / PC
	 Red / Netflix / Search
	 AV / Input / RDS
	 Rec / Rec Mode
	 TV/Radio /
	 Exit / Cancel / Clear
	 Sound / Title
	 Zoom / Size

