











































































Original	Replacement
	 AV / Input / RDS
	 Power
	 Shift + 4
	 Shift + 2
	 Shift + 5
	 Shift + 7
	 Picture / Format
	 Shift + Zoom /
	 Subtitle / EQ
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 >> / Tune+
	 Guide / EPG / -/--
	 Up
	 Text / Goto


Original	Replacement
	 Left
	 Right
	 OK
	 Down
	 Menu / Home
	 Vol+
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 4
	 5
	 6
	 7










































































	Original	Replacement	Original	Replacement
	8	 8		
	9	 9		
	[i+]	 Info / Angle		
	0	 0		
	P<P	 Fav / Marker / PC		
	♪ Smart	 Sound / Title		
	[-o-]/Active Control	 D.Menu / Top		
	[] Smart	 Smart / List		
	[o]	 TV/Radio /		
	Setup	 Setup / OPT /		
	[+]	 Display / Media		
	[♦]/Zoom	 Zoom / Size		
	[]	 Audio / Lang I/II		
	Instant	 Back / Return		
	[<>]	 Sleep / Timer		
	[↔]	 Eject / Surround		








































Original	Replacement	Original	Replacement
	 AV / Input / RDS		 Right
	 Power		 OK
	 Shift + 4		 Down
	 Shift + 2		 Menu / Home
	 Shift + 5		 Vol+
	 Shift + 7		 CH+ / Page+
	 Zoom / Size		 Vol-
	 Subtitle / EQ		 Mute / Dimmer
	 Red / Netflix / Search		 CH- / Page-
	 Green / APP / Repeat		 1
	 Yellow / YouTube / Repeat		 2
	 Blue / Prime Video / Random		 3
	 >> / Tune+		 4
	 Guide / EPG / -/--		 5
	 Up		 6
	 Text / Goto		 7
	 Left		 8






Original	Replacement
	 AV / Input / RDS
	 Power
	 Shift + 4
	 Shift + 2
	 Shift + 5
	 Shift + 7
	 Zoom / Size
	 Subtitle / EQ
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 >> / Tune+
	 Guide / EPG / -/-
	 Up
	 Text / Goto
	 Left

Original	Replacement
	 Right
	 OK
	 Down
	 Menu / Home
	 Vol+
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8





Original	Replacement	Original	Replacement
	Input / RDS		Vol+
	Power		CH+ / Page+
	Shift + 4		Vol-
	Shift + 2		Mute / Dimmer
	Shift + 5		CH- / Page-
	Shift + 7		1
	Subtitle / EQ		2
	Green / APP / Repeat		3
	>> / Tune+		4
	Guide / EPG / -/--		5
	Up		6
	Text / Goto		7
	Left		8
	Right		9
	OK		0
	Down		Fav / Marker / PC
	Menu / Home		

