































































































Original	Replacement
 Standby	 Power
 Open/Close	 Eject / Surround
 Setup	 Setup / OPT /
 Angle	 Info / Angle
 Random	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide / EPG / -/-
 Language	 Audio / Lang I/II

Original	Replacement
 Display	 Display / Media
 Title	 Sound / Title
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 Search	 Red / Netflix / Search
 Repeat	 Green / APP / Repeat
 A-B	 Yellow / YouTube / Repeat
 Zoom	 Zoom / Size
 Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Play	 Play / Slow
 Vol+	 Vol+
 I<<	 I<< / Preset-





Original		Replacement	
	>>		>> / Preset+
	Vol-		Vol-
	<<		<< / Tune-
	>>		>> / Tune+
	Resume		Smart / List
	Subtitle		Subtitle / EQ
	Slow		Shift + Play /
	Program		TV/Radio /
	Vocal-Assist		Picture / Format
	PBC		D.Menu / Top
	Mute		Mute / Dimmer
	P/I		AV / Input / RDS

Original		Replacement	

