






























































































| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------|
|  | Mute |  | Mute / Dimmer |
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | PRE-CH |  | Fav / Marker / PC |
|  | 0 |  | 0 |
|  | List |  | Smart / List |
|  | Vol+ |  | Vol+ |
|  | [i] |  | Info / Angle |
|  | P+ |  | CH+ / Page+ |
|  | Vol- |  | Vol- |
|  | * |  | D.Menu / Top |
|  | P- |  | CH- / Page- |
|  | Home |  | Menu / Home |
|  | Up |  | Up |
|  | = |  | Setup / OPT / |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Back |  | Back / Return |
|  | Down |  | Down |
|  | Input |  | AV / Input / RDS |
|  | Exit |  | Exit / Cancel / Clear |
|  | Guide |  | Guide / EPG / -/- |
|  | Text |  | Text / Goto |
|  | Lang |  | Audio / Lang I/II |
|  | Subt. |  | Subtitle / EQ |





| Original | Replacement | Original | Replacement |
|---|--|----------|-------------|
|  | Red  Red / Netflix / Search | | |
|  | Green  Green / APP / Repeat | | |
|  | Yellow  Yellow / YouTube / Repeat | | |
|  | Blue  Blue / Prime Video / Random | | |
|  | <<  << / Tune- | | |
|  | Pause  Pause / Step / Freeze | | |
|  | >>  >> / Tune+ | | |
|  | Zoom  Zoom / Size | | |
|  | Play  Play / Slow | | |
|  | Stop  Stop / Hold | | |
|  | Netflix  +  Shift + Red / Netflix / | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

