















































































Original	Replacement	Original	Replacement
	Hold		Options
	Power		Power
	Sleep		Sleep
	TV		TV/R
	AV		AV
	Scart		Smart
	PC		Media
	Display		Info
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	Enter		Ok
	Menu		Menu
	TTX/MIX		Text
	Wide		Format
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	OK		Play
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Index		Back





	Original	Replacement		Original	Replacement
	Subtitle	 Subt			
	Size	 List			
	Subpage	 Dual			
	Reveal	 Exit			
	Red	 Red			
	Green	 Green			
	Yellow	 Yellow			
	Blue	 Blue			
	MPX	 Shift + Smart			

