



Original	Replacement	Original	Replacement
 Power	 Power	 6/Video	 Comp / Video
 3D	 3D / Invert	 7/PgDn	 Vol - / Page -
 Source	 Source	 8/Media	 Eco / Aspect
 Ratio	 Blank / Mute	 9/LAN/WIFI	 Help / Info
 Mode	 Mode	 0/Hide	 Shift + 3D /
 Up	 Up	 Zoom In	 + / Play
 Down	 Down	 Zoom Out	 - / Stop
 Right	 Right		
 Left	 Left		
 Enter/Play/Pause	 Enter		
 Stop/Back	 Shift + Power		
 Menu	 Menu		
 1/Freeze	 Freeze / Timer		
 2/VGA	 Auto		
 3/HDMI/MHL	 Volt / Focus		
 4/PgUp	 Vol + / Page +		
 5/Component	 Shift + Comp / Video		

