






























Original	Replacement
	Mute
	[<>]
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	AV
	0
	Swap
	Swap
	PC

Original	Replacement
	TV
	Menu
	Text / Mix
	Up
	Left
	OK
	Right
	Down
	Vol+
	PR+
	Vol-
	PR-
	Red
	Green
	Yellow
	Blue
	[ i ]



