







































































Original	Replacement
 Power	 Power
 Audio I/II	 Dual
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Sleep	 Sleep
 Recall	 Back
 Exit	 Exit
 Menu	 Menu

Original	Replacement
 Source	 AV
 Info	 Info
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Vol +	 Vol +
 Vol -	 Vol -
 CH +	 Ch +
 CH -	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 P.Mode	 Format
 S.Mode	 Shift + Dual





Original	Replacement	Original	Replacement
P.Size	Eject		
Subtitle	Subt		
Play/Pause / TS	Play		
Play/Pause / TS	Pause		
Stop	Stop		
Rec	Rec		
Text	Text		
<< / PVR List	<<		
<< / PVR List	List		
>> / DTV/Radio	>>		
>> / DTV/Radio	TV/R		
I<< / Fav.CH	I<<		
I<< / Fav.CH	Pre Ch		
>>I / Guide	>>I		
>>I / Guide	Guide		

