

























































































































| Original | Replacement | Original | Replacement |
|--------------|---|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Audio Off |  Mute | Menu Right |  Right |
| Slow Down |  Ch - | Return |  Back |
| Stop |  Stop | Menu Down |  Down |
| Pause |  Pause | Volume+ |  Vol + |
| Auto/Track |  Red | Progr. |  Sleep |
| Slow Up |  Ch + | Next |  >> |
| Subt. |  Subt | Volume- |  Vol - |
| Rep/A-B |  +  Shift + Text | Top Menu |  D. Menu |
| Title |  List | Prev. |  << |
| DVD/TV |  Media | 1 |  1 |
| Repeat/1/All |  Text | 2 |  2 |
| Zoom |  +  Shift + Eject | 3 |  3 |
| Menu |  Menu | 4 |  4 |
| Menu Up |  Up | 5 |  5 |
| Display |  +  Shift + Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Replacement | Original | Replacement |
|--------------|--|--------------|---|
| 8 |  8 | ON/Off |  +  Shift + Power |
| 9 |  9 | Mode |  Smart |
| Store |  Green | Key- |  +  Shift + Left |
| Digest |  Yellow | Input Source |  AV |
| Random |  +  Shift + Format | 3D |  3D |
| Play |  Play | F.Forward |  >> |
| Game |  Blue | Play/Back |  +  Shift + Play |
| +10 |  Guide | Timer |  +  Shift + AV |
| Np |  +  Shift + List | Open/Close |  Eject |
| Remain |  Exit | Resume |  +  Shift + Pause |
| Karaoke/Step |  +  Shift + >> | Audio |  +  Shift + Dual |
| Shuffle |  +  Shift + TV/R | Key+ |  +  Shift + Right |
| 0 |  0 | Vocal/Assist |  +  Shift + Vol + |
| C/CH |  Pre Ch | Search |  TV/R |
| Record |  Rec | Tone |  +  Shift + Vol - |
| Video |  Options | Info |  Info |
| Rewind |  << | Angle |  Format |



| Original | Replacement | Original | Replacement |
|--------------|--|------------|---|
| On/Off |  Power | OK Enter |  Ok |
| Audio Off |  Mute | Menu Right |  Right |
| Slow Down |  Ch - | Progr. |  Sleep |
| Subt. |  Subt | Return |  Back |
| Auto/Track |  Red | Menu Down |  Down |
| Slow Up |  Ch + | Top Menu |  D. Menu |
| Rep/A-B |  +  Shift + Text | Volume+ |  Vol + |
| Title |  List | Volume- |  Vol - |
| Stop |  Stop | 1 |  1 |
| Pause |  Pause | 2 |  2 |
| Repeat/1/All |  Text | Next |  >> |
| Zoom |  Eject | 3 |  3 |
| DVD/TV |  AV | 4 |  4 |
| Menu |  Menu | Prev. |  << |
| Menu Up |  Up | 5 |  5 |
| Display |  +  Shift + Info | 6 |  6 |
| Menu Left |  Left | 7 |  7 |



| Original | Replacement | Original | Replacement |
|-------------|--|-----------|---|
| Rewind |  << | 8 |  8 |
| Play |  Play | Audio |  +  Shift + Dual |
| Record |  Rec | Info |  Info |
| Np |  Green | 9 |  9 |
| Angle |  Format | +10 |  Guide |
| Video |  Smart | 0 |  0 |
| Remain |  Blue | C/CH |  Pre Ch |
| Pbc |  Yellow | ON/Off |  +  Shift + Power |
| Syst.Preset |  Media | Key- |  +  Shift + Left |
| F.Forward |  >> | Auto Scan |  +  Shift + Ok |
| Setup |  Options | Key+ |  +  Shift + Right |
| Timer |  +  Shift + AV | Echo+ |  +  Shift + Ch + |
| 3D |  3D | Echo- |  +  Shift + Ch - |
| Play/Back |  +  Shift + Play | Digest |  +  Shift + Guide |
| Shuffle |  +  Shift + TV/R | | |
| Lang |  Dual | | |
| Random |  +  Shift + Format | | |

