








































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right

Original	Replacement	Original	Replacement
	Left		Left
	OK		Ok
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red		Red
	Yellow		Yellow
	Blue		Blue
	Green		Green
	EPG		Guide
	Subtitle		Subt
	TTX		Text
	Audio		Dual
	i		Info
	FAV		Pre Ch
	Tv/Radio		TV/R





Original		Replacement		Original	Replacement
	Video		Smart		
	Scan		Media		
	Device		Options		
	File		List		
	Zoom		Eject		
	Roll		AV		
	Record		Rec		
	Prev.		I<<		
	Next		>>I		
	Play		Play		
	Pause		Pause		
	<<		<<		
	>>		>>		

