






















| Original | Replacement | Original | Replacement |
|--|---|---|---|
|  Power |  Power |  Up |  Up |
|  1 |  1 |  Down |  Down |
|  2 |  2 |  Right |  Right |
|  3 |  3 |  Left |  Left |
|  4 |  4 |  Vol+ |  Vol + |
|  5 |  5 |  Vol- |  Vol - |
|  6 |  6 |  P+ |  Ch + |
|  7 |  7 |  P- |  Ch - |
|  8 |  8 |  Mute |  Mute |
|  9 |  9 |  i |  Info |
|  0 |  0 |  EXIT |  Exit |
|  ↔ |  FAV PRE-CH |  Source |  AV |
|  BACK |  RETURN BACK |  Q. MENU |  E-MANUAL D.MENU |
|  MENU |  TOP MENU MENU |  EPG |  - / - / GUIDE |
|  NETFLIX |  APP MEDIA |  TXT |  REPEAT TEXT |
|  Internet |  HOME SMART |  * |  PICTURE FORMAT |
|  OK |  OK |  */Q |  ECO 3D |





| Original | Replacement | Original | Replacement |
|--|--|----------|-------------|
|  [>] |  Options | | |
|  Lang |  Dual | | |
|  Subt. |  Subt | | |
|  Shift + Format |  Shift + Format | | |
|  TV |  TV/R | | |
|  Red |  Red | | |
|  Green |  Green | | |
|  Yellow |  Yellow | | |
|  Blue |  Blue | | |
|  Rec |  Rec | | |
|  Play |  Play | | |
|  Stop |  Stop | | |
|  Pause |  Pause | | |
|  << |  << | | |
|  >> |  >> | | |

