



| Original | Replacement |
|---|-------------------|
|  | Power |
|  | Mute / Dimmer |
|  | Picture / Format |
|  | Sleep / Timer |
|  | Fav / Marker / PC |
|  | TV/Radio / |
|  | Smart / List |
|  | Shift + 0 |
|  | Zoom / Size |
|  | Subtitle / EQ |
|  | Vol+ |
|  | Info / Angle |
|  | CH+ / Page+ |
|  | Vol- |
|  | Back / Return |
|  | CH- / Page- |
|  | Menu / Home |

| Original | Replacement |
|---|-----------------------------|
|  | Text / Goto |
|  | Guide / EPG / -/- |
|  | Exit / Cancel / Clear |
|  | Up |
|  | Shift + CH- / |
|  | Left |
|  | OK |
|  | Right |
|  | Shift + CH+ / |
|  | Down |
|  | Red / Netflix / Search |
|  | Green / APP / Repeat |
|  | Yellow / YouTube / Repeat |
|  | Blue / Prime Video / Random |
|  | 1 |
|  | 2 |
|  | 3 |





| Original | | Replacement | | Original | | Replacement | |
|----------|---------|-------------|-----------------|----------|--|-------------|--|
| | 4 | | 4 | | | | |
| | 5 | | 5 | | | | |
| | 6 | | 6 | | | | |
| | 7 | | 7 | | | | |
| | 8 | | 8 | | | | |
| | 9 | | 9 | | | | |
| | Speaker | | Sound / Title | | | | |
| | 0 | | 0 | | | | |
| | ✓ | | Display / Media | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

