






















































































Original		Replacement		Original		Replacement	
	Power		Power		8		8
	Display		Shift + Info		9		9
	DTV Menu		Shift + Menu		0		0
	TV		TV/R		-/--		Shift + Guide
	PC		Smart		PRE		Back
	Line		Media		Vol+		Vol +
	List		List		Vol-		Vol -
	OPT		Options		Prog+		Ch +
	EPG		Guide		Prog-		Ch -
	i		Info		Red/M/S		Red
	1		1		Green/Still		Green
	2		2		Yellow/Sleep		Yellow
	3		3		Blue/P.Size		Blue
	4		4		Tv Menu		Menu
	5		5		[≡x]/Exit		Exit
	6		6		Mute		Mute
	7		7		[≡]/TTX		Text





Original	Replacement
 Up/P+	 Up
 Down/P-	 Down
 Right/Vol+	 Right
 Left/Vol-	 Left
 Enter	 Ok
 Open/Close	 Eject
 Setup	 Shift + D. Menu
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 <</<I Slow	 <<
 Slow I>/>>	 >>
 I<</<II Step	 I<<
 Step II>/>>I	 >>I
 Rec	 Rec
 Input	 AV
 PIP On/Off	 Shift + 3D

Original	Replacement
 PIP Sound	 Shift + Dual
 [=+]/Repeat	 Shift + Text
 [=i]/A-B	 Format
 [/≡]/Audio	 Dual
 [=o]/Subtitle	 Subt
 [=?]/Goto	 Pre Ch
 Title	 Sleep
 Angle	 Shift + Subt
 Menu	 D. Menu
 Zoom	 Shift + Eject
 Bookmark	 3D

