




































































Original	Replacement	Original	Replacement
 Power	 Power	 9	 9
 P.Mode	 Format	 0	 0
 S.Mode	 List	 Prev. PR	 Pre Ch
 PIP Swap	 3D	 Audio / I/II	 Dual
 Still	 Pause	 PR +	 Ch +
 Mute	 Mute	 PR -	 Ch -
 TV	 TV/R	 Vol +	 Vol +
 AV	 AV	 Vol -	 Vol -
 Multimedia	 Media	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Menu	 Menu
 4	 4	 Right	 Right
 5	 5	 Down	 Down
 6	 6	 S.Effect	 Shift + Dual
 7	 7	 i / Recall	 Back
 8	 8	 Edit	 Info





Original		Replacement		Original		Replacement	
	Sleep		Sleep				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Text		Text				
	Reveal		Smart				
	[≡X] / PIP Source		Shift + AV				
	[≡⇅] / PIP PR +		Shift + Ch +				
	PIP		Options				
	PIP Position		Eject				
	PIP PR -		Shift + Ch -				

