Mandis shop

RE1911-1

Original		Replacement		Original		Replacement	
	Power		Power				
MUTE	Mute	MUTE	Mute				
1	Source 1	1	1				
2	Source 2	2	2				
3	Source 3	3	3				
	Bluetooth	HOME SMART	Smart				
VOLUME +	Volume+	+ VOL	Vol +				
VOLUME −	Volume-	VOL −	Vol -				
BASS +	Bass+	+ CH	Ch +				
BASS −	Bass-	CH −	Ch -				
	Blue	D	Blue				
	Red	A	Red				
	Green	B	Green				
	Yellow	C	Yellow				