





















Original	Replacement
	Mute / Dimmer
	Picture / Format
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	AV / Input / RDS
	0
	Back / Return
	D.Menu / Top
	Fav / Marker / PC

Original	Replacement
	TV/Radio /
	Menu / Home
	Text / Goto
	Up
	Left
	OK
	Right
	Down
	Vol+
	CH+ / Page+
	Vol-
	CH- / Page-
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Info / Angle





Original		Replacement	
	[?]		Smart / List
	[+]		Zoom / Size
	[♦]		Display / Media
	[≡x]		Eject / Surround
	[:≡]		Guide / EPG / --
	[ ]		Subtitle / EQ
	♪		Sound / Title

Original		Replacement	

