


























Original		Replacement		Original		Replacement	
	Power		Power		<<		<< / Tune-
	Open/Close		Eject / Surround		>>		>> / Tune+
	Subtitle		Subtitle / EQ		V-Mode		Picture / Format
	Angle		Info / Angle		Repeat		Green / APP / Repeat
	Language		Audio / Lang I/II		Zoom		Zoom / Size
	Setup		Setup / OPT /				
	Menu		Menu / Home				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Play		Play / Slow				
	Slow		Shift + Play /				
	Pause/Step		Pause / Step / Freeze				
	Stop		Stop / Hold				
	I<<		I<< / Preset-				
	>>I		>>I / Preset+				

