



Original	Replacement
 Power	 Power
 TV / SAT	 Smart
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 P +	 Ch +
 P -	 Ch -
 SAT	 Media
 Menu	 Menu

Original	Replacement
 EPG	 Guide
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Exit	 Exit
 Info	 Info
 TV	 TV/R
 Radio	 Shift + TV/R
 FAV	 Pre Ch
 Red / Lang	 Red
 Red / Lang	 Dual
 Blue / Pause	 Blue
 Blue / Pause	 Pause
 Green / Sound	 Green
 Green / Sound	 Shift + Dual





Original	Replacement	Original	Replacement
 Yellow / Subtitle	 Yellow		
 Yellow / Subtitle	 Subt		

