















































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Pause	 Pause
 Recall	 Back
 Fav	 Pre Ch
 Menu	 Menu
 i	 Info

Original	Replacement
 EPG	 Guide
 Sat	 Smart
 Exit	 Exit
 Up	 Up
 Prog +	 Ch +
 Down	 Down
 Prog -	 Ch -
 Right	 Right
 Vol +	 Vol +
 Left	 Left
 Vol -	 Vol -
 Ok	 Ok
 TV / Radio	 TV/R
 Zoom	 Eject
 Page -	 I<<
 Page -	 <<
 PIP	 List





	Original	Replacement		Original	Replacement
	F1	 Options			
	Page +	 >>			
	Page +	 >>			
	UHF	 Format			
	P/N	 3D			
	TV/SAT	 Media			
	Subtitles	 Subt			
	Red / Audio	 Red			
	Audio	 Dual			
	Green / Mosaic	 Green			
	Yellow / Clock	 Yellow			
	Text	 Text			
	Blue / Text	 Blue			

