







































































Original	Replacement	Original	Replacement
 Power	 Power	 OK	 Ok
 Mute	 Mute	 Up	 Up
 Movie	 1	 Down	 Down
 Music	 2	 Right	 Right
 Photo	 3	 Left	 Left
 Home	 Smart	 Stop	 Stop
 Disk	 Menu	 Pause	 Pause
 All Media	 Media	 <<	 <<
 Subtitle	 Subt	 >>	 >>
 Audio	 Dual	 <<	 <<
 Zoom	 Eject	 >>	 >>
 Info	 Info	 Repeat	 Text
 Copy Target	 Pre Ch	 Tv Out	 TV/R
 Vol+	 Vol +	 Setup	 Options
 Vol-	 Vol -	 A-B	 D. Menu
 P+	 Ch +	 BGM/Go to	 Format
 P-	 Ch -	 Slide Type	 Guide

