





























































Original	Replacement	Original	Replacement
	Power		Ch -
	1		>>
	2		<<
	3		Up
	4		Down
	5		Right
	6		Left
	7		Ok
	8		Menu
	9		Back
	0		Red
	Info		Green
	Guide		Yellow
	Mute		Blue
	Vol +		<<
	Vol -		Play
	Ch +		Pause





Original	Replacement	Original	Replacement
 >>	 >>		
 Stop	 Stop		
 Rec	 Rec		
 PVR	 Smart		
 FAV	 Pre Ch		
 [+] / Ratio	 3D		
 Page Up	 Shift + Up		
 Page Down	 Shift + Down		
 [v] / Edit	 Media		
 F1 / Tv / Radio	 TV/R		
 F2 / Input	 AV		
 F3	 Subt		
 F4	 Options		

