

























































































Original	Replacement
 Power	 Power
 Aspect	 Picture / Format
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 List	 Smart / List
 0	 0
 Repeat	 Shift + Green / APP /
 Vol +	 Vol+
 S	 D.Menu / Top

Original	Replacement
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Audio	 Audio / Lang I/II
 CH -	 CH- / Page-
 i	 Info / Angle
 Home	 Shift + Home / Menu /
 Mouse	 Display / Media
 Menu	 Menu / Home
 Up	 Up
 Input	 AV / Input / RDS
 Left	 Left
 OK	 OK
 Right	 Right
 Back	 Back / Return
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Red	 Red / Netflix / Search



Menu



Original	Replacement
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Index / Stop	 Stop / Hold
 Hold / Play/Pause	 Play / Slow
 Hold / Play/Pause	 Pause / Step / Freeze
 Reveal / <<	 << / Tune-
 Size / >>	 >> / Tune+
 Fav	 Fav / Marker / PC
 TV.RD	 TV/Radio /
 Mix / I<<	 I<< / Preset-
 S.Page / >>I	 >>I / Preset+
 Text	 Text / Goto
 Cancel	 Shift + Exit / Cancel / Clear
 Guide	 Guide / EPG / -/--
 Rec	 Rec / Rec Mode

Original	Replacement

