



































































































Original	Replacement	Original	Replacement
	Power		Power
	TV		TV/R
	Q.Menu		Menu
	Picture		Format
	Sound		Shift + Dual
	Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	List		List
	Q.View		D. Menu
	FAV		Pre Ch
	I/II		Dual
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Page+		Ch +
	Page-		Ch -
	Time		Shift + AV
	Reveal		Media
	Update		Subt
	Settings		Options
	Hold		Smart
	Up		Up
	Down		Down
	Right		Right
	Left		Left





Original		Replacement		Original		Replacement	
	OK		Ok				
	Back		Back				
	Exit		Exit				
	Text		Text				
	Stop		Stop				
	<<		<<				
	Index		Info				
	Play		Play				
	Pause		Pause				
	>>		>>				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

