









































































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV / Input / RDS
	P.Mode		Setup / OPT /
	S.Mode		Sound / Title
	Home		Shift + Menu /
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Q.View		D.Menu / Top
	0		0
	Sleep		Sleep / Timer
	Vol-		Vol-
	Vol+		Vol+
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	I/II/Audio		Audio / Lang I/II
	P-		CH- / Page-
	Subtitle		Subtitle / EQ
	3D World		Display / Media
	Info		Info / Angle
	FAV		Fav / Marker / PC
	Screen		Picture / Format
	CH List		Smart / List
	Menu		Menu / Home
	Up		Up
	Guide		Guide / EPG / -/--
	Left		Left
	OK		OK





Original	Replacement	Original	Replacement
	 Right		
	 Back / Return		
	 Down		
	 Exit / Cancel / Clear		
	 Red / Netflix / Search		
	 << / Tune-		
	 Green / APP / Repeat		
	 >> / Tune+		
	 Yellow / YouTube / Repeat		
	 I<< / Preset-		
	 Blue / Prime Video / Random		
	 >>I / Preset+		
	 Text / Goto		
	 Play / Slow		
	 Pause / Step / Freeze		
	 Stop / Hold		
	 Rec / Rec Mode		

