







































































Original	Replacement	Original	Replacement
 Power	 Power	 Yellow	 Yellow
 Input	 AV	 Blue	 Blue
 1	 1	 [=]	 Menu
 2	 2	 Pause	 Pause
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Back	 Back
 9	 9	 Exit	 Exit
 0	 0	 Vol+	 Vol +
 Guide	 Guide	 Vol-	 Vol -
 CH.List	 List	 Home	 Smart
 Play	 Play	 Micro	 Media
 Red	 Red	 CH+	 Ch +
 Green	 Green	 CH-	 Ch -





Original		Replacement		Original		Replacement	
	Subtitle		Subt				
	Mute		Mute				
	Text		Text				
	Free		Options				
	Sports		TV/R				
	Chili		Dual				
	Netflix		Shift + Media				
	prime video		3D				
	YouTube		Pre Ch				
	TV Timvision		Shift + TV/R				
	Rakuten Tv		D. Menu				
	Rai Play		Shift + Smart				

