



Original	Replacement	Original	Replacement
 Power	 Power	 7	 7
 Mute	 Mute	 8	 8
 Audio	 Dual	 9	 9
 TV / STB	 Shift + TV/R	 0	 0
 TV / R	 TV/R	 PGUP	 Vol +
 Sleep	 Sleep	 PGDN	 Vol -
 SUB	 Subt	 SAT	 Shift + AV
 TXT	 Text	 FAV +	 Ch +
 Multi	 Smart	 FAV -	 Ch -
 P / N	 Shift + 1	 EPG	 Guide
 Recall	 Pre Ch	 Fav	 Shift + Pre Ch
 1	 1	 Up / CH+	 Up
 2	 2	 Right / Vol+	 Right
 3	 3	 Down / CH-	 Down
 4	 4	 Left / Vol-	 Left
 5	 5	 OK	 Ok
 6	 6	 Menu	 Menu





Original	Replacement
 Exit	 Exit
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Pause	 Pause
 Zoom	 Eject
 Edit	 Format
 Info	 Info
 USB	 AV
 MP3	 Media
 JPEG	 Shift + Media
 PVR List	 List
 PIP	 Shift + Ok
 A - B	 Back
 T.S.	 Shift + 2
 Goto	 Options

Original	Replacement
 Stop	 Stop
 Rec	 Rec
 <<	 <<
 >>	 >>
 Play / Pause	 Play
 > <	 Shift + Pause
  <<	  <<
 >>	 >>

