




















| Original  | Replacement | Original  | Replacement   |
|---|-------------|---|---------------|
|      | Power       |      | Power         |
|      | Exit        |      | Exit          |
|      | Display     |      | Shift + Info  |
|      | TV/AV       |      | AV            |
|      | 1           |      | 1             |
|      | 2           |      | 2             |
|      | 3           |      | 3             |
|      | 4           |      | 4             |
|      | 5           |      | 5             |
|      | 6           |      | 6             |
|     | 7           |     | 7             |
|    | 8           |    | 8             |
|    | 9           |    | 9             |
|    | 0           |    | 0             |
|    | Recall      |    | Pre Ch        |
|    | Back        |    | Back          |
|    | -/--        |    | Shift + Guide |
|    | [≡?]        |    | Smart         |
|    | [≡⇅]        |    | Eject         |
|    | [ /≡]       |    | Shift + Text  |
|    | [≡□]        |    | Stop          |
|    | [≡●]        |    | Media         |
|    | [≡i]        |    | List          |
|    | [≡]         |    | Text          |
|    | Menu 1      |    | D. Menu       |
|    | Exit 1      |    | Shift + Exit  |
|    | Info        |    | Info          |
|   | Up          |   | Up            |
|  | Left        |  | Left          |
|  | OK          |  | Ok            |
|  | Right       |  | Right         |
|  | Down        |  | Down          |
|  | Pause       |  | Pause         |
|  | PGUP        |  | Shift + Ch +  |



