







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol-		Vol -
	Mute		Mute		1		1
	Source		AV		2		2
	Tv/AV		TV/R		3		3
	I/II		Dual		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	*/SSM		Smart		7		7
	Stop		Stop		8		8
	Up		Up		9		9
	Down		Down		0		0
	Right		Right		Swap		Pre Ch
	Left		Left		Auto		Guide
	OK		Ok		[≡]/Text		Text
	PR+		Ch +		Sleep		Sleep
	PR-		Ch -		[≡M]/Mode		Options
	Vol+		Vol +		[≡x]/Update		Subt





Original	Replacement	Original	Replacement
 Blue/List	 Blue		
 Yellow/Q.View	 Yellow		
 Green/APC/PSM	 Green		
 Red/PIP	 Red		
 POP	 Media		
 [≡i]/Index	 Info		
 [≡o]/Time	 List		
 [≡♦]/Size	 Format		
 [≡+]/Hold	 Eject		
 [.=]/Mix	 D. Menu		
 [≡?]/Reveal	 3D		

